Installation Instructions for

Round or Square Type Non-IC Down Light Housing with CMH Electronic Ballast for Flanged Trims

Intertek

1




This instruction shows a typical installation.

GENERAL PRODUCT INFORMATION:

ELEMEN

a brand of **TECH** LIGHTING **CMH MR16 - ROUND/SQUARE FLANGELESS**

Install the Housing with Adjustable Bars




NOTE: Skip this section if installing the housing with butterfly brackets.

• Keep Tab for ceiling ½" to ¾" thick.

When using adjustable hanger bars with 1/2" to 3/4" thick ceilings, leave the tab of the hanger bars in place. Break off Tab for ceiling ³/₄" or thicker. When using adjustable hanger bars with 3/4" or thicker ceilings, remove the tab by bending it at the perforation. 17

CAUTION - RISK OF FIRE This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Use minimum 90°c supply conductors.






three housing clasps. Make sure the nail is on top.


3 Slide and push the outer adjustable bar completely onto the inner adjustable bar so that the tab clicks into place behind the stop point. This will prevent the adjustable bars from coming apart.

Repeat steps 2 & 3 for the other side of the housing.


2 Slide the inner adjustable bar completely through the







E3 F -CDN




6 Adjust the trim holder position (horizontal position) by sliding the housing on adjustable bars.

When the desired location is achieved, tighten the two #6 self tapping screws to lock the housing onto the adjustable bars.


NOTE: Notches in trim holder can be used to align multiple housings using a laser or string.

Install the Housing with Butterfly Brackets





NOTE: Skip this section if installing the housing with butterfly brackets.

- Squeeze the two tabs on the lamp housing to unsnap it.
- 2 Swing the lamp housing back.



Line up the square cut out section of the butterfly bracket with the housing slot. Make sure the cut out corner of the butterfly bracket is against the housing edge.








Tighten the wing nut (Not Completely) to the button head screw threads.

8 Slide the butterfly bracket up or down to achieve the proper location. Tighten the wing nut to secure the butterfly bracket in place.

9 Repeat steps 3 through 8 on pages 2 and 3 for the other butterfly bracket.






• Swing the lamp housing down until the tabs lock it in place.

Utilize the butterfly brackets to install the housing in accordance with local electrical codes.


> **NOTE:** Notches in trim holder can be used to align multiple housings using a laser or string.

12 Follow "Connect Power to the Housing" on page 4.


Connect Power to the Housing



Push the tab on the housing electrical box up and remove the electrical box cover.



WARNING: RISK OF FIRE: When using the housing electrical box for power feed through, use **MAX** 4 - #12 AWG, or 6 - #14 AWG branch circuit wires.




3 Run the power line wires into the housing electrical box.

4 Connect the neutral power line wire to the white transformer wire and the white thermal protector wire with a wire nut.

5 Connect the hot power line wire to the black thermal protector wire with a wire nut.


6 Make sure that housing is grounded in accordance with local electrical codes.






7 Replace the electrical box cover. Make sure that the top edge of the cover snaps under the tab.


Install the Lamp & Lens Accessories




Pull the snoot to remove the lamp cartridge assembly.



Unscrew the snoot from the lamp cartridge.





3 Place a maximum of three accessories (optional) into the lamp cartridge.





 Replace and tighten the snoot completely to the lamp cartridge.









9 Pull out the socket from the lamp housing.

• Push the lamp pins into the large portion of the socket slots and rotate the lamp clockwise to lock it in place securely.



Slide the lamp holder spring completely onto back of the MR16 lamp so that the edge of the lamp snaps into the lamp cartridge assembly.






8 Feed the socket wire sleeve back into the lamp housing.

 Align the arrow indicator on the lamp cartridge assembly with the cut out section of the lamp housing. Push to snap the lamp cartridge assembly into the lamp housing.


NOTE: Before installing drywall (or acoustic panel), it is recommended to power up and run the Element fixture(s) for 10 minutes to make sure that all electrical connections are tight and secure.

Install Drywall or Suspended Ceiling



For housings with round trim holder, mark a 3-7/8" diameter circle on drywall (or acoustic panel). Cut out the marked section.

For housings with square trim holder, mark a 3-7/8" square on drywall (or acoustic panel). Cut out the marked section.



Align the cut out section of drywall (or acoustic panel) with the trim holder and install drywall (or acoustic panel).

WARNING: <u>Risk of Fire:</u> The housing is not intended to be in contact with or covered with combustible materials and insulation. Do not install insulation within 3 inches of the housing sides or above in such a manner to entrap heat.

Notes:

SAVE THESE INSTRUCTIONS!



7400 Linder Ave, Skokie, IL 60077 847.410.4400

www.element-lighting.com

© 2015 Tech Lighting, L.L.C. All rights reserved. The "Element" graphic is a registered trademark of Element. Element reserves the right to change specifications for product improvements without notification. A Generation Brands Company